


396-100014

TT-301



Install hose clamp around the shank and placement tube, just above the inside disc scraper. This will hold the tube against the bottom of the shank.

Installation Instructions:

1. Remove depth gauge wheels and disc openers, making sure to note correct shim placement.
2. Find the 1/4" casting hole in the shank. This is approximately 1" above and 2" forward of the threaded disc opener attachment hole. Drill this hole out to 9/32
3. Lift the placement tube up into place and insert the enclosed 1/4" cap screw thread it into the weld nut on placement tube mounting tab. Use the enclosed hose clamp to secure tube firmly to scraper as shown in picture above.
4. Tighten cap screw
5. Attach zip tie in existing hole in planter to tube as shown in picture.
6. Reinstall disc openers.

Due to the variances in Kinze planters, two sizes of bolts have been provided. 1" and 7/8"; use the bolt that best fits your planter.