


396-4864Y1 Kinze 4905 16R Hitch Mounted Tank Kit Mounting Instructions




Kit Number: 530-03-450140 (400 Gallon)

Kit Number: 530-03-450150 (500 Gallon - No Markers) Kit Number: 530-03-450160 (600 Gallon - No Markers) Kit Number: 530-03-450175 (750 Gallon - No Markers)






ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	421-1333A2	Elliptical Cradle - 400 Gallon	1
2	421-2020A1	Cradle Support Stand - 400/500 Gallon	2
3	727-01-HE0400-57-W	Elliptical Tank - 400 Gal - White	_1
4	330-10	5/8" Flat Washer	12
5	300-100108-5	5/8" x 1-1/2" Hex Head Bolt - G5	12
6	323-10	5/8" Flange Nut	12
7	380-1066	3/4" U-bolt Kit - fits 8" x 12" tube - (8" opening)	4
8	525-3000	3" Tank Strap Kit - 400/500 Gallon	2






ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	421-1329A2	Elliptical Cradle - 500 Gallon	1
2	421-2020A1	Cradle Support Stand - 400/500 Gallon	2
3	727-01-HE0500-57-OS-W	Elliptical Tank - 500 Gal - White	1
4	330-10	5/8" Flat Washer	12
5	300-100108-5	5/8" x 1-1/2" Hex Head Bolt - G5	12
6	323-10	5/8" Flange Nut	12
7	380-1066	3/4" U-bolt Kit - fits 8" x 12" tube - (8" opening)	4
8	525-3000	3" Tank Strap Kit - 400/500 Gallon	2






ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	421-4105Y1	Elliptical Tank Cradle - 600 Gallon	1
2	421-2424Y2	600/750 Gallon Tank Pedestal	2
3	727-01-HE0600-64-CS-W	Elliptical Tank - 600 Gal - White	1
4	300-100108-5	5/8" x 1-1/2" HCS	12
5	323-10	5/8" Flange Nut	12
6	330-10	5/8" Flat Washer	12
7	380-1066	3/4" U-bolt Kit - fits 8" x 12" tube - (8" opening)	4
8	525-750	3" Tank Strap Kit	3






ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	421-2364Y1	Elliptical Tank Cradle - 750 Gallon	1
2	421-2424Y2	1775NT - 750 Gallon Tank Stand	2
3	727-01-HE0750-69-OS-W	Elliptical Tank - 750 Gal - White	1
4	300-100108-5	5/8" x 1-1/2" HCS	24
5	330-10	5/8" Flat Washer	24
6	323-10	5/8" Flange Nut	24
7	380-1066	3/4" U-bolt Kit - fits 8" x 12" tube - (8" opening)	4
8	525-750	3" Tank Strap Kit	3







Step by Step Instructions

- 1. Loosely bolt the 3/4" U-Bolts on the pedestals and move rear pedestal toward the back of the planter until the rear U-Bolt touches the rear cylinder gusset. Loosely mount front bracket in front of the rear bracket to match your tank cradle profile.
- 2. Place the tank cradle on the pedestals and loosely bolt them together using the 5/8" bolts, washers, and nuts.
- Place the tank in the cradle. Line the tank strap grooves up to the holes in the cradle. Use the tank strap kits to tighten the tank to the cradle.
- 4. Make sure the tank and cradle have proper clearance from CCS tanks (should be approximately 1 2" of clearance). Tighten down U-Bolts and all other hardware. If your planter has markers, be sure to note the best point of marker clearance on your cradle. If you attempt to fold the planter with the hitch all the way down you will be in danger of hitting the side of the tank with your markers. Be sure to raise the hitch as much as possible before folding to prevent any contact with the tank.
- Tighten tank straps after first filling.










Kinze 4905 Fill Kit

Kit Number: 520-00-250500

Description: Kinze 4905 Hitch Tank 2" Fill/Discharge Kit

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	101-075075	3/4" MPT x 3/4" HB	1
2	102-200MVCF	2" Manifold Ball Valve	2
3	102-200VSFCF	200 Series Manifold x 2" Male Quick Coupler Std Port Valve	1
4	105-150G	1-1/2" EPDM Gasket	9
5	105-200150BRB	2" Manifold x 1-1/2" HB	1
6	105-200150BRB45	2" Manifold x 1-1/2" HB - 45 Degree	1
7	105-200150MPT	2" Manifold x 1-1/2" Male	1
8	105-200BRB	2" Manifold x 2" HB	3
9	105-200BRB45	2" Manifold X 2" HB - 45 Degree	1
10	105-200MPT	2" Manifold x 2" MPT	1
11	105-200PLG075	2" Manifold Plug x 3/4" FPT	1
12	105-200SWP90	2" Manifold Sweep - 90 Degree	2
13	105-200TEE	2" Flanged Tee Fitting	1
14	105-FC200	2" Manifold Clamp	9
15	106-200CAP	2" Cap	1
16	280-200-ENF	2" Enforcer Fertilizer Solution Hose	20'
17	300-050508-5	5/16" x 5-1/2" Hex Head Bolt - G5	2
18	300-060100-5	3/8" x 1" Hex Head Bolt - G5	2
19	302-UB222	M220 U-Bolt Assembly - 2 U-Bolt Kits	1
20	323-05	5/16" Flange Nut	2
21	323-06	3/8" Flange Nut	2
22	330-05	5/16" Flat Washer	2
23	350-PS238	Pressure Seal HD Clamp, Size 238 - 1.625" - 2.125" (1-1/4" - 1-1/2" ENF, WBS or AG200 Hose)	2
24	350-PS288	Pressure Seal HD Clamp, Size 288 - 2.125" - 2.625" (2" ENF or WBS Hose)	2
25	353-24	24" Zip Tie	10
26	400-4583Y1-BK	Fertilizer Hose Support Bracket	2
27	435-4974Y1	Kinze 4905 Bulk Fill Stair Fill Kit Mounting Bracket	1

*Strainer not included in kit



- 1. Mount the 435-4974Y1 bracket to the holes provided in the stairs using the 3/8" x 1" bolts and nuts.
- 2. Assemble the fill/discharge kit as shown below. Thread the correct size pipe threaded manifold into the bottom tank bung. Use the provided plug to plug the second bung.
- Route the 2" enforcer hose from the fill port to the plumbing assembly under the tank. Make sure to keep the hose away from row units and any moving parts.



Over the Tire Pump Mounting Kit

Kit Number: 515-03-201300

Description: Kinze 4905 12R/16R Over the Tire Pump Mounting Kit

Instruction Sheet: 396-2937Y1

