



# 396-7160Y1

## Retention Chain Installation Instructions, for Banjo Camlock Caps and Plugs

A retention chain [771-910-2710-01] has been provided in your kit. One chain for each Banjo CamLock style cap and plug.

### Instructions:

**Step 1 – Attach one end of chain’s “Key-Ring” to cap or plug using the plastic loop or attached ring.**

**Step 2 – Attach other end of chain to plumbing part that the cap or plug goes to.**

**A. Most valves will have a molded plastic loop to attach chain**

**B. If no loop available attach chain under nearby bolt and washer on valve or bracket. (In this example valve body bolt was reversed to avoid chain ring under a lock washer)**

**C. Chain loop can attach using Banjo manifold Clamp**

