



Step by Step Instructions

1. Loosely mount 400-3985Y1 to toolbar using two (2) U-bolts, nuts, and washers.
2. Loosely mount desired Flow Indicator/Sentinel Mounting Bracket to 400-3985Y1 using the hardware provided in the kit.
3. Tighten everything down once brackets are in their desired location.

