396-02-7373 Inertial Movement Unit (IMU)

417-7960Y1 IMU Mounting Instructions


About

The IMU (P/N: 226-01-7495Y1) provides movement data to the MVX system. Install it with the correct orientation to ensure proper operation.

Installation


To install the IMU:

1. Mount the mounting bracket to the implement. See the MVX installation manual for mounting details.
2. Install the IMU on the bracket. The illustrations below show the correct orientation.



The IMU must be oriented so that the connector is opposite the direction of travel. The body of the IMU must be perpendicular to the the implement bar.

Back view



The IMU must be mounted level with the ground or parallel to the implement bar

Parallel to the ground and level.

SurePoint Ag Systems